





1. Plug the headset in to Headset port on the back of your Yealink phone as shown below:

- 2. To use the headset, press the "headset" button on the phone. This will activate the headset.
- 3. To disconnect your headset, pick up the handset **or** press the headset button again.