



YEALINK T54W DESKPHONE INSTRUCTIONS

YEALINK T54 DESKPHONE INSTRUCTIONS

Voicemail

- 1. Dial 999 or press Message (envelope shaped image) button on your desk phone.
- 2. Enter PIN number. New messages will automatically play.

Record Greetings

- 1. Dial your voicemail.
- 2. Enter PIN
- 3. Press 9 for settings.
- 4. Press 8 to record greeting.
- 5. Press 0 to confirm, then record greeting after beep.
- 6. Press pound to save recording. This will automatically be set as your default recording.

Set Profile Status

- 1. Dial your voicemail.
- 2. Enter PIN.
- 3. Press 9 for settings.
- 4. Press 1 for profile status.
- To select available, press 1. To select away, press 2. To select Out of Office, press
 For custom profile 1, press 4. For custom profile 2, press 5.

Call Forwarding

- 1. Go to Menu.
- 2. Go to features.
- 3. Go to Call forwarding.
- 4. Select which kind of call forwarding you would like to set.
- 5. Enable your forwarding setting.
- 6. Enter your preferred forwarding phone number (the number you want to receive forwarded calls).
- 7. Press save.

Hold

- 1. Press Hold button, found on right hand side of phone.
- 2. You may put down your handset on the receiver.
- 3. To take a call off hold, pick up the handset and press hold again.
- 4. To take a call off hold on speaker, press hold without picking up the handset.

Mute

- 1. Press the Mute button found on the righthand side of the phone to mute your phone.
- 2. To unmute, press the Mute button again.

Hands-free Speakerphone

- 1. To dial a speakerphone call, dial the outgoing number without picking up the handset.
- 2. To put an ongoing call on speaker, press the speakerphone button on the bottom right of the phone. You can then hang up the handset.

Transferring Calls

- 1. Press transfer on the phone (TRAN).
- 2. Dial the desired extension.
- 3. Hang up the phone.

Redial

- 1. Press the redial button on the phone (Circular arrows).
- 2. Select your desired recent number. (To dial most recent number, press redial twice.)
- 3. Press OK from the arrow pad to put through the call.